

Movie Tones v 1.0 by Rock Your Mobile!

User manual



Movie Tones v.1.0



User Manual



Index

Index.....	2
General Description.....	3
Compatible Devices	3
General requirements	3
How to install Movie Tones	3
How to register Movie Tones.....	4
Working with Movie Tones	4
Working with Projects.....	4
Creating a Video Ring Tone.....	4
Step 1: Creating a Project.....	4
Step 2: Choosing Audio Stream	4
Step 3: Add Video Frames	5
Step 4: Optimizing the frames set	7
Step 5: Video Preview	7
Step 6: Building Video Ring Tone	8
Using Movie Tones on the mobile	8
Installing Movie Tone on the mobile	8
Setting up Movie Tone	9
Uninstalling Movie Tone on the mobile	9
Options of Movie Tones Application.....	9
Clear frames dialog on open.....	9
Settings	9
How to uninstall Movie Tones	10
Uninstalling PC Client	10
Uninstalling Mobile Player	10



General Description

Movie Tones Software generates video ring tones for your mobile using your video and audio content.

Video ring tone is a mobile application that is installed on the mobile phone and lets a video to be played during somebody is calling you. The video ring tone has all the features of a normal ring tone: you may choose it from the list of the ring ones and let it play in some profile, or when a user group or a user from your address book is calling you.

Compatible Devices

Version 1.0 of Movie Tones is compatible with **Windows XP** on the PC Side and **Nokia 7650, 3650, 6600, 6630, 6670, 3660, N-Gage, 6260, 7610; Nokia 6680, 6681, 6682 ; Nokia N70; Panasonic X700 and X800; Samsung D720 and D730** on the mobile side.

General requirements

In order to be able to generate Video Ring Tones you need the following:

- audio file that will be played as a ring tone in your video ring tone. Such audio file can be in the following formats: ***wav, *rmf, *mid, *midi or *rng**. Please do not forget to test the audio file as a normal audio ring tone before, in the video ring tone it will sound in the same way.
- Video file, a fragment from which you would like to insert as video in your video ring tone. You can use any framed video format for which you have video codecs installed. Mostly it will be **AVI** format.
- In this version you can also extract video fragment from **DVD**!

How to install Movie Tones

Installation on PC: In the installation package of Movie Tones there is a setup.exe. Please run the Setup and follow installation instructions.

If you are not sure if you have all required **codecs** for the video we recommend to click “**Install video codecs**” at the end of the installation. During codecs installation just click “Next” – there are all required options checked already.

Installation on Smartphone:

In your Installation Package you will find . Please install this player on your mobile. Now you are ready to install the video ring tone files, that were generated by your PC Movie Tones Programm. **Please be sure to install MovieTones Player on your mobile before installing MovieTones ring tone.**

Please be sure that you do not have another Graphical Caller software turned on. In case you have such software please turn it off.

In some cases you will need to restart mobile after installation or MovieTones player.

After installation of player you can try test tone test_mvt.SIS.

After installation of test_mvt.SIS just select test.mvt as ringtone for current profile or selected contact.

The same apply to your own tones generated with MovieTones software.



How to register Movie Tones

Trial Version of Movie Tones is fully functional with the exception that there is a “trial” text over all video ring tones that you generate. After registration you will receive full version of the Movie Tones Player. Please uninstall trial version and install registered one on your mobile.

You do not need to regenerate your ring tones once more after registration. With registered version all ringtones will be without covered “trial” text.

In order to obtain your registered Movie Tones Player you have to purchase Movie Tones Application. The registered player you will obtain in course of 24 hours after the Product Purchase. You can purchase Movie Tones on www.rock-your-mobile.com . Registration code is for copyright reasons based on your email and IMEI number.

Note: registered Movie Tones Player will run only on the mobile with the IMEI provided.

Working with Movie Tones

Working with Projects

Every Movie Tone on your PC is prepared as a project. A project is a file in .mtp format where the information about your future video ring tone is saved.

You may:

- Create a new Project by going to “Tones – New” or pressing CTRL+N
- Open your saved Project going to “Tones – Open” or pressing CTRL+O
- Save your current Project going to “Tones – Save” or pressing CTRL+S
- Save your current Project in a special location going to “Tones – Save As” and choosing project name and path
- Preview current Project on the PC going to “Tones – Preview”
- Create a video ring tone from the current project going to “Tones – Build”

Please note: a project can be previewed only on your PC; in order to be able to use a video ring tone on your mobile you have to build your ring tone from the current project going to “Tones – Build”.

Creating a Video Ring Tone


To create a video ring tone you have to make the following Steps:

Step 1: Creating a Project

Create a new Movie Tones Project or open an existing one as described above. (By default always a New Project is created).

Step 2: Choosing Audio Stream

Choose the audio stream that will be used in your video ring tone. Such audio file can be in the following formats: *wav, *rmf, *mid, *midi or *rng. Please do not forget to test the audio file as a normal audio ring tone on the mobile, in the video ring tone it will sound in the same way.



Step 3: Add Video Frames

You can add frames that will be played as a video in the following ways:

- add frames from video by going to “Frames – Add Video Frames” or pressing Insert Button
- add frames from image by going to “Frames – Insert Image”

Adding Frames from Video

In the frames window choose the position where you would like to add new frames.

To add frames from video please go to “Frames – Add Video Frames” or press “Insert” button. In the “Add video Frames” window choose video that you would like to get frames from. Press button “...” if you are going to get frames from a video file and choose this file from the file system.

Press button “DVD” if you would like to get frames from DVD and choose the DVD directory (or a DVD Disk) in your file system.

Wait some time till the video will be opened by the Movie Tones Application. It may take some time depending on the size of your video.

In the frame to the right you will be able to view the following information:

Total frames count: how many frames has the opened video.

Note: in some formats and also in DVD it is not possible to count frames, so the video duration will be displayed in seconds.




Current position: number of the current frame/current position

Selection start: frame with which you would like to start your frame selection for the video ring tone. To set a start frame, press Pause in the place where you would like to start selecting frames and click on the ">" button to the left from the Selection Start pane.

Selection end: frame with which you would like to end your frame selection for the video ring tone. To set an end frame, press Play button again and let the video play till the frame that you would like to have as a last frame. Press Pause and then the button ">" to the left from the Selection end frame.

Grab each N-th frame: sometimes you will wish to grab not every frame, but every 2nd or every 3rd frame, just choose the number N.



After you have set the start and the end frame, press **"Get Frames"**. The piece of the video chosen will be played and frames will appear in the window below.

If you are satisfied with your selection press **"Append"** and append the grabbed frames to your video ring tone project. (you will be able to move the frames and to delete some of them later)

If you are not satisfied, press **"Clear all"** and get frames once more as described above.




Adding Frames from Image

In the frames window choose the position where you would like to add new frames.

To add frames from image please go to “Frames – Insert Image” or press “CTRL+I”.
Choose the image from your file system and press “Open”.
The image will be appended to your Movie Tones Project.
You may use images in various formats.

Step 4: Optimizing the frames set

In the main application window you can see all the frames that you have added to the project.



You can manage the frames in the following way:

Browse through the grabbed frames with mouse or with arrows

Move a selected frame to the right or to the left by choosing “Frames – Move right” or “Frames – Move left” respectively.

Delete selected frame by choosing “Frames – Delete”

Delete all frames by choosing “Frames – Delete All”

Of course you can always add new frames from video or from picture as described in the Step 3.

Step 5: Video Preview

You can preview your project by choosing “Tones – Preview”.

Please note that on the mobile the speed of the video can differ due to the hardware difference.



Step 6: Building Video Ring Tone

If you are satisfied with the ring tone preview and are ready to generate video ring tone, please go to “Tones – Build”.

Choose a Movie Tone title – a name of the video ring tone that will be displayed in the list of the ring tones on the mobile after the installation.

Then choose name and path for the SIS file that will be generated.

Wait till the file is generated.

Using Movie Tones on the mobile

Installing Movie Tone on the mobile

In your installation package you have received the MovieTones.SIS. This is the trial player of your video ring tones. Please transfer it to the mobile and install in the usual way.



Now send the SIS file you have created with your PC Movie Tones Application to your mobile phone using cable, Bluetooth or Infrared. Confirm the installation and install the application in a usual way.

Setting up Movie Tone


After the installation please go to your ring tone settings in the Profiles. Please choose the name of the Movie Tone you have just installed (Name that you have entered in the “MVT Title” field during building) and set this ring tone to the profile, a group or a contact of your choice.

Uninstalling Movie Tone on the mobile

To uninstall Movie Tone go to the device’s Control Panel, choose the name of the Movie Tone that you would like to uninstall and uninstall the application in a usual way.

Options of Movie Tones Application

You can access Settings of Movie Tones going to menu item “Options”.



Clear frames dialog on open

Choose this option to clear all grabbed frames in “Add video frames” dialog each time you open it.

Settings

There are the following Settings you can use:

- **Frames per 10 seconds:** recommended value here is 100, the higher this value the better quality and bigger size will the ring tone have
- **JPEG Export quality:** recommended value is 30%, the higher this value is the better quality and bigger size will the ring tone have
- **Target device:** please choose the target device here. Please note that you will have to restart the application for changes to take effect.
- **Language:** here you can choose the language of Movie Tones Application from the list. Currently the following languages are available: English, German. The default language is



German if your language settings are set to German. Otherwise the default language will be English.

- **Show video format warning:** Activating this option will display warning-message box each time you open video file in “Add Frames from Video” dialog. This option is recommended if your video file format does not support grabbing frames

How to uninstall Movie Tones

Uninstalling PC Client

In order to uninstall PC Client of Movie Tones please go to the Control Panel, choose the Movie Tones Application and uninstall it in the usual way.

Uninstalling Mobile Player

To uninstall the Mobile Player of Movie Tones go to the device’s Control Panel and uninstall the application in a usual way.